

DATE

26DEC17

SCALE

NONE

SHEET

1 OF 2

MEMBRANE HOUSING

NUMBER

99110

REV

٧

SIZE

В

CHECKED

APPROVED

DATE

DATE

**KPS** 

MKS

13DEC16

13DEC16

\*FC PORT, BEARING PLATE & RETAINING RING MATERIALS ARE

AS PER STAMPED APPLICABLE ASME EDITION.

\*EMPTY WEIGHT REFERS TO SHELL WEIGHT INCLUDING HEAD ASSEMBLIES WITHOUT MEMBRANES.

2

(16)

(17)

52245

45069

Adapter seal

Thrust Ring

 $^{+}3$  &  $^{++}6$  Each Furnished With Length Code 4, 5, 6 & 7.

Ethylene Propylene - O - Ring

Engineering Thermoplastic.

#### **RATING:**

DESIGN PRESSURE	1200 PSI
	(8.27 Mpa)
MAX.OPERATING TEMP	120°F
	(49°C)
MIN.OPERATING TEMP	20°F
	(-7°C)
FACTORY TEST PRESSUREC	CE / ASME
1800 PS	SI / 1320 PSI
(12.41Mpa)	) / (9.10 MPa)
BURST PRESSURE	7200 PSI
	(49.64 MPa)

#### INTENDED USE:

The CodeLine Model 80E120 Fiberglass RO Pressure Vessel is designed for continuous, long term use as a housing for reverse osmosis membrane elements to desalt typical sea waters at pressures up to 1200 psi. Any make of eight-inch nominal diameter spiral-wound element is easily accommodated; the appropriate interfacing hardware for the element specified is furnished with the vessel.

The CodeLine Model 80E120 is designed in accordance with the engineering standards of the Boiler and Pressure Vessel Code of the American Society of Mechanical Engineers (ASME Code) Section X. At small additional cost, vessels can be inspected during construction by an ASME Authorized inspector and ASME Code stamped.

The CodeLine Model 80E120 must be installed, operated and maintained in accordance with the listed precautions and good industrial practice to assure safe operation over a long service life.

The high performance reinforced plastic shell must be allowed to expand under pressure; undue restraint at support points or piping connections can cause leaks to develop in the shell. The end closure, incorporating close fitting, interlocking metal components, must be kept dry and free of corrosion; deterioration can lead to catastrophic mechanical failure of the head.

The end closures, incorporating close-fitting, interlocking metal components, must be kept dry and free of corrosion; deterioration can lead to catastrophic mechanical failure of the heads.

Pentair will assist the purchaser in determining the suitability of this standard vessel for their specific operating conditions. The final determination however, including evaluation of the standard material of construction for compatibility with the specific corrosive environment, shall be the responsibility of the purchaser.

Specifications are subject to change without notice.

#### PRECAUTIONS:

- DO...read, understand and follow all instructions; failure to take every precaution will void warranty and may result in vessel failure
- DO...mount the shell on horizontal members at span "S" using complaint vessel supports furnished; tighten hold down straps just snug
- DO...provide overpressure protection for vessel set at not more than 105% of design pressure
- DO...inspect end closures regularly; replace components that have deteriorated and correct causes of corrosion
- DO NOT... make rigid piping connections to ports or clamp vessel in any way that resists growth of fiberglass shell under pressure;  $\Delta DIA = 0.015$  in. (0.4mm) and  $\Delta L = 0.2$  in. (5mm) for a length code -7 vessel
- DO NOT... hang piping manifolds from ports or use vessel in any way to support other components; branch connection piping may be simply supported between the header and port; maximum weight of branch piping; feed/concentrate 16 lbs (7.3 kg); permeate 8 lbs (3.6 kg)
- DO NOT... operate vessel at pressures and temperatures in excess of its rating
- DO NOT... operate vessel without permeate ports internally connected with a complete set of elements and interconnecting hardware
- DO NOT... operate vessel with permeate pressure in excess of 125 psi at 120°F (0.86 MPa @ 49°C)
- DO NOT... overtighten the connection to the permeate port (hand-tighten plus one-quarter turn, check for leaks)
- DO NOT... tolerate leaks or allow end closures to be routinely wetted in any way
- DO NOT... pressurize vessel until doublechecking to verify that the retaining ring is completely inside the groove
- DO NOT... work on any component until first verifying that pressure is relieved from vessel
- DO NOT... operate outside the pH range 3-11

#### **ORDERING:**

Using the chart below, please check the features you require and fax them with your purchase order to our customer service department for expedited processing.

For optional materials and/or features not listed below, please consult factory for pricing and availability.

Please note that we require your membrane brand and model number when ordering. If this information is not initially available, you may provide it at a later date by checking the appropriate box below.

## VESSEL LENGTH CODE - please check one

MODEL 80E120 □ -1 □ -2 □ -3 □ -4 □ -5 □ -6 □ -7 □ -8

# MEMBRANE BRAND AND MODEL - please check one and fill in information

☐ Plea	se supply adapters for	or the following membi	rane brand and	specific mode
Brar	d	Model		

### CERTIFICATION REQUIRED

- ☐ ASME Stamped and National Board Registered (please consult factory for pricing)
  ASME Section X
- CE Marked
- ☐ Standard, Certified by Pentair.

## EXTERIOR FINISH – please check one

- ☐ Standard white high-gloss polyurethane coating.
- Option optional colors are available for 50 or more vessels per order.
   Call factory for pricing details.

## MATERIAL OPTIONS

- ☐ Standard All materials as per drawing 99110 on the first page.
- ☐ Customer specified materials: (Please consult the factory, as these options will affect pricing and vessel lead-time.)

For complete information on proper use of this vessel please refer to the 80E series USER'S GUIDE Bulletin 523004.